

SMART VINYL OVER VINYL WALLPAPER ADHESIVE

APPLICATION GUIDE

Smart Vinyl Over Vinyl Wallpaper Adhesive is a vinyl over vinyl adhesive suitable for most wallcoverings, including products that require high strength adhesive.

1 PREPARE THE SURFACE

- Ensure all surfaces are clean and dry.

2 APPLY PRIMER

- Apply primer to any filler or porous surfaces such as new plaster. Gloss and non porous surfaces should be lightly sanded before priming.

3 ADD WATER + STIR

- Add 5% water to your adhesive and stir well before use.

4 FOR WALLCOVERING APPLICATION

- Evenly apply one solid uniform coat of adhesive to the surface with a short pile roller or brush and place the wallcovering, cut to size, in the wet adhesive.
- Adjust the material as necessary into the correct position.
- Use a smooth plastic edge to push excess adhesive out behind the wallcovering, working from the centre to the edges and ensure no air bubbles are trapped. Press the entire surface firmly to the wall.
- If you find air bubbles, push them out to the edges as required and wipe off any excess adhesive with water and a cloth.
- When using as a border or overlapping adhesive: Moisten the borders with water and then apply a thin, uniform coat of adhesive to the border.
- Check the entire surface for air bubbles again.

5 FOR USE WITH JOINT REPAIRS

- Open the joint to be repaired if required.
- Apply the adhesive behind the joint and work the wallcovering as required, applying pressure with a suitable wallpapering tool.
- Press firmly into position and wipe off any excess adhesive with water and a cloth.

6 INSPECT THE SURFACE

- Wait thirty minutes and reinspect the surface for bubbles. Use a spatula to push them firmly out to the edge.

PRODUCT LIABILITY CLAUSE

The sale of our products is subject to our General Terms and Conditions available on www.smartersurfaces.com

SUPPORT

 **EMAIL:**
support@smartersurfaces.com

 **PHONE (IRE):**
+353 1 412 6200

 **WEBSITE:**
www.smartersurfaces.com